



Application of PoE Installation with Splitter



PWR LED on:
AC Power Connected

PoE LED on:
PoE Power being Delivered

PoE LED flash:
Overload Protection